

Solenoid Operated Isolation Valves

100T2NC, Normally Closed
Isolation Valve



100T2NO, Normally Open
Isolation Valve



100T3MP, 3-Way
Isolation Valve



Bio-Chem Valve™ Isolation Valves offer instrument designers a completely inert, non-metallic fluid path. The valves use a flexible diaphragm to isolate the solenoid actuation mechanism from the fluid path. Isolation valves offer low internal volumes, precise flow control and excellent ease of installation.

Bio-Chem Valve™ Isolation Valves are particularly suitable for use in highly aggressive and / or high purity fluid applications such as analytical chemistry and clinical diagnostics. The highly inert fluid path is especially useful in liquid chromatography, genomics and protein synthesis applications. The high flow factor makes these valves well suited to environmental and water analysis applications.

FEATURES

- **Choice of valve function**
 - 2-way normally closed
 - 2-way normally open
 - 3-way
- **Inert fluid path** - The fluid path in a Bio-Chem Valve™ Isolation Valve can be made entirely from extremely inert materials such as PTFE (polytetrafluoroethylene) and PEEK (polyetheretherketone).
- **Choice of materials**

Valve bodies are available in PPS (polyphenylene sulfide), PEEK and PTFE. Diaphragms are available in FFKM (perfluoro elastomer), EPDM (ethylene-propylene-diene) and PTFE. (Not all combinations of materials are available in all sizes or configurations).
- **Choice of valve orifice sizes**

Precisely machined valve orifice sizes from 0.032" (0.81mm) to 0.156" (3.96mm) in four different dimensional frames ensures that the most appropriate design for your application can be selected from standard configurations.



Long life cycles


The actuation mechanism in our Bio-Chem Valve™ Isolation Valves is rated to over 20 million cycles.

ISOLATION VALVE - OPERATION

Bio-Chem Valve™ Isolation Valves are available in three different configurations; normally closed, normally open and 3-way. When the valve is energized, the solenoid retracts the armature that is attached to a flexible diaphragm. In a normally closed valve, this raises the diaphragm allowing fluid to flow between the inlet and outlet ports. For a normally open valve, the operation is reversed. When the valve is energized, the diaphragm presses down to close the fluid path.

3-way valves have three ports referred to as normally closed, normally open and common. When the valve is de-energized, fluid flows between the normally open and the common port. When the valve is energized, the valve switches and fluid flows between the normally closed and the common port.

Bio-Chem Valve™ Isolation Valves identify the preferred inlet port on the valve label. However, all valves can be used in any flow direction.



ISOLATION VALVE - SELECTION GUIDE

2- way Normally Closed Valves

| Valve Part number | Max Pressure | Valve Orifice | Cv Int. Vol. |
|----------------------|-----------------|------------------|-----------------|
| 038T2Bxx-32 | 20 psi | 0.032" | 0.008 18µl |
| 038T2Bxx-54 | 20 psi | 0.054" | 0.015 35µl |
| 038T2Sxx-32 | 20 psi | 0.032" | 0.008 20µl |
| 038T2Sxx-54 | 20 psi | 0.054" | 0.015 42µl |
| 075T2NCxx-32 | 20 psi | 0.032" | 0.011 19µl |
| 075T2NCxx-62 | 20 psi | 0.062" | 0.030 54µl |
| 100T2NCxx-62 | 30 psi | 0.062" | 0.042 55µl |
| 100T2NCxx-92 | 15 psi | 0.092" | 0.080 133µl |
| 100T2NCxx-125 | 10 psi | 0.125" | 0.105 296µl |
| 150L2NCxx-156 | 15 psi | 0.156" | 0.110 293µl |

| Material Options | | |
|------------------------|-----------------------|------------------------|
| PTFE body diaphragm | PPS body diaphragm | PEEK body diaphragm |
| - NA - | PTFE EPDM FFKM | PTFE EPDM FFKM |
| - NA - | PTFE EPDM FFKM | PTFE EPDM FFKM |
| - NA - | PTFE EPDM FFKM | PTFE EPDM FFKM |
| - NA - | PTFE EPDM FFKM | PTFE EPDM FFKM |
| PTFE | PTFE EPDM FFKM | PTFE EPDM FFKM |
| PTFE | PTFE EPDM FFKM | PTFE EPDM FFKM |
| PTFE | - NA - | PTFE |
| PTFE | - NA - | - NA - |
| PTFE | - NA - | - NA - |

MANIFOLD MOUNTING



The Bio-Chem Valve™ Isolation Valves described here are supplied with threaded ports making them suitable for installation with standard ¼"-28 UNF fittings (⅛" NPT on 150L series valves). Custom manifolds save space and eliminate complicated plumbing inside instruments. To meet this demand, Bio-Chem Fluidics offers both normally closed and normally open isolation valves with a manifold mounting option.

Typically, manifold mounted valves have a threaded collar that attaches the valve to the manifold. A locating pin ensures the correct orientation and an elastomer gasket seals the flow path. Contact your local Bio-Chem Fluidics office for more information and complete manifold interface details.

2-way Normally Open Valves

| Valve Part number | Max Pressure | Valve Orifice | Cv Int. Vol. |
|----------------------|-----------------|------------------|-----------------|
| 075T2NOxx-32 | 20 psi | 0.032" | 0.011 19µl |
| 075T2NOxx-62 | 20 psi | 0.062" | 0.030 54µl |
| 100T2NOxx-62 | 30 psi | 0.062" | 0.042 55µl |
| 100T2NOxx-92 | 10 psi | 0.092" | 0.080 133µl |




| Material Options | | |
|------------------------|-----------------------|------------------------|
| PTFE body diaphragm | PPS body diaphragm | PEEK body diaphragm |
| PTFE | PTFE | PTFE |
| PTFE | PTFE | PTFE |
| PTFE | PTFE EPDM FFKM | PTFE EPDM FFKM |
| PTFE | - NA - | PTFE |




3-way Valves

| Valve Part number | Max Pressure | Valve Orifice | Cv Int. Vol. |
|----------------------|-----------------|------------------|-----------------|
| 075T3MPxx-32 | 15 psi | 0.032" | 0.010 45µl |
| 075T3MPxx-46 | 15 psi | 0.046" | 0.023 52µl |
| 100T3MPxx-32 | 30 psi | 0.032" | 0.010 47µl |
| 100T3MPxx-62 | 30 psi | 0.062" | 0.028 87µl |
| 150L3MPxx-156 | 15 psi | 0.156" | xxx xxxµl |

| Material Options | | |
|------------------------|-----------------------|------------------------|
| PTFE body diaphragm | PPS body diaphragm | PEEK body diaphragm |
| PTFE | PTFE EPDM* FFKM* | PTFE EPDM* FFKM* |
| PTFE | PTFE EPDM* FFKM* | PTFE EPDM* FFKM* |
| PTFE | PTFE | PTFE |
| PTFE | PTFE | PTFE |
| PTFE | - NA - | - NA - |

* EPDM & FFKM diaphragms rated to 10 psi in 075T2MP valves





MOUNTING OPTIONS

Bio-Chem Valve™ Isolation valves are easy to mount using one of our stock mounting accessories. The MU-series mounting flanges allow direct attachment to a bulkhead - either inside or outside the panel.

Features:


- Constructed from sturdy, glass-filled polypropylene
- Spring steel retainer and set screw ensure a secure fit
- Surface withstands alcohol, bleaches and other common cleaning agents
- Screw hole orientation relative to fluid ports can be adjusted to fit available system space.

MU-series flanges



Integrated mounting holes (standard on 038T and 150L models) can be added to all isolation valves as a standard option. Typically 2 or 4 #4-40 UNC threaded holes are machined into the base of the valve providing direct mounting to the instrument.

Aluminum mounting rings (MR-075 & MR-100) and steel mounting clips (MC-075 & MC-100) are also available. Both provide economic options for securing the valves within an instrument.



MR-series ring

MC-series clip

CUSTOMIZED SOLUTIONS

We understand that many applications require customized solutions. Our design and prototyping expertise enables us to offer simple modifications of standard products as well as completely customized designs. Over 90% of the solenoid valves we sell are customized to one extent or another. Customizable options include (but are not limited to):

- Materials of construction
- Operating voltage
- Mounting options
- Tagging / labeling
- Length and/or style of connecting leads
- Custom manifolds

We look forward to working with you to meet your design engineering objectives!

BIO-CHEM
FLUIDICS

www.biochemfluidics.com

Bio-Chem Valve™ is a trademark of Bio-Chem Fluidics Inc

Bio-Chem Fluidics Inc

85 Fulton Street, Boonton, NJ 07005 USA

t: 973 263 3001 f: 973 263 2880 e: sales.us@biochemfluidics.com

Bio-Chem Fluidics Ltd

2 College Park, Coldhams Lane, Cambridge CB1 3HD UK

t: +44 (0) 1223 416642 f: +44 (0) 1223 416787 e: sales.eu@biochemfluidics.com

Bio-Chem Fluidics Technology (Shanghai) Co. Ltd

South Metropolis Industrial Park, Jindu Road, Minhang District, Shanghai, PRC 201108

t: +86 21 61519058 f: +86 21 61519090

BCF IVSS February 2011